

WC 100 Security Bracket Installation Guide



CONTENTS

- (1) Security Bracket
- (2) Bezel Mount 6/32" x 1/2" Screws
- (4) Wall Mount Screws
- (4) Zip-It

REQUIRED TOOLS

- 1/4" Sheetrock Drill Bit
- Level
- Phillips Screwdriver or Bit

1

Attach the bracket to the wall with screws through the mounting plate holes indicated in pink.

2

Attach the clock to the security bracket through the 2 holes in the bezel indicated in blue.