

# Parallel Horizontal Mounting Instructions



- 1) Attach the lower rail to wall at desired elevation and level. (lower rail has grooves on top and bottom)
- 2) Set panels in groove with dado edge in bottom rail.
- 3) Set top rail on panels, so that the dado edge goes into groove. (top rail has one flat edge. Flat edge is the top)
- 4) Attach top rail to wall. Insure that the top and bottom rails are level and plumb.
- 5) Place panel divider (aluminum strip with tape on 2 sides) between glass and cork board. Adhere divider to panels. Front of divider should be flush with rails.
- 6) Attach end panel trim (aluminum strip with tape on 1 side) on each end panel. Front of panel trim should be flush with rails.
- 7) Slide in magazine pocket and hooks into lower groove of lower rail. Secure with set screws in desired position.
- 8) Attach cover extrusion to top and bottom rails by aligning tabs into slots.
- 9) Attach end caps (4) with machine screws provided. End caps have plastic tabs to lock cover extrusion in place. The end cap should be positioned so the tabs are on the lower part of end cap.

