

Parallel Vertical with Shelf :: Mounting Guide



1

Place the left vertical rail atop the shelf, flush with the shelf edge.

Attach the left vertical rail to wall via pre-drilled holes and the supplied drywall screws.

Make certain the rail is plumb.

Slide panel(s) into the left rail.

2

Slide right rail onto the panel(s) and attach the right vertical rail to wall via pre-drilled holes and the supplied drywall screws.

Make certain the rail is plumb.

3

Screw shelf to the left and right vertical rails, through bottom of shelf with (4) supplied machine screws.

4

Attach panel divider (for two panels) and top panel trim (aluminum strip with tape on one side).

Top panel trim should be flush with rails.

5

Attach cover extrusions to side rails by aligning tabs into slots.

6

Slide optional hooks into side grooves and tighten.

Secure with set screws in desired position.

7

Attach (2) top end caps with (4) screws provided.

End caps have plastic tabs to lock cover extrusion in place.

The end cap should be positioned so the tabs are towards the inside of rail.