

## PMS-E : INSTALLATION INSTRUCTIONS FOR STORAGE DOOR BASE

- 1** REMOVE DOORS AND SHELVES
- 2** LAY CASE ON BACK
- 3** REMOVE BOTTOM FRAME OF SHOWCASE BY LOOSENING THE 4 ALLEN SCREWS(JUST A COUPLE OF TURNS) LOCATED ON THE INSIDE OF THE BASE. THE SCREWS ARE LOCATED IN THE VERTICAL FRAME MEMBERS IN THE GROOVE ABOUT 1-1/4" ABOVE THE CORNER. USE THE 3MM ALLEN WRENCH PROVIDED.
- 4** ONCE THE SCREWS ARE LOOSE, PULL THE ENTIRE BOTTOM FRAME OFF THE SHOWCASE. IT MAY NEED TO BE TAPPED WITH A RUBBER MALLET FROM THE INSIDE, THROUGH THE BOTTOM.
- 5** REMOVE THE HARDBOARD PANEL FROM THE FRONT SIDE WHERE THE DOORS WILL BE PLACED.
- 6** REPLACE THE BOTTOM FRAME AND TIGHTEN THE 4 ALLEN SCREWS.
- 7** INSERT THE BLACK PANEL INTO THE BOTTOM OF THE BASE AREA. THIS WILL JUST SIT ON TOP OF THE CUT OUT PORTION OF THE BOTTOM PANEL. IF DESIRED USE SILICONE ADHESIVE.
- 8** SNAP PRE-CUT PLASTIC DOOR TRACK INTO GROOVE IN FRAME. THERE ARE 2 SIDES AND 1 TOP AND BOTTOM TRACK. USE A RUBBER MALLET IF NECESSARY.
- 9** INSERT THE DOOR(WITHOUT LOCK) INTO THE REAR GROOVE, TOP FIRST THEN LIFTING THE BOTTOM OVER THE LOWER TRACK. INSERT THE FRONT DOOR INTO THE FRONT TRACK.
- 10** REPLACE SHELVES AND DOORS.

PLEASE NOTE: THESE INSTRUCTIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.



Peter Pepper Products, Inc. • T: 310.639.0390 x 7 • F: 310.639.6013 • E: [customerservice@peterpepper.com](mailto:customerservice@peterpepper.com)