

CLEANING AND MAINTENANCE FOR CLOCKS

Acrylic clock covers should be cleaned monthly to remove dust particles.

A feather duster will work in most cases unless a greasy film exists then a clean soft cotton cloth and a "WINDEX" type product with "no" ammonia will be suitable for this application.

The clock housing may also be cleaned with this type of product.

IMPORTANT

Do not use an abrasive cleanser or cloth as it may scratch the cover and finish.

The AA Alkaline Battery should be replaced each spring and fall when the local time is reset for the change to /from daylight savings time.

PLEASE NOTE: THESE INSTRUCTIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.



Peter Pepper Products, Inc. • T: 310.639.0390 x 7 • F: 310.639.6013 • E: customerservice@peterpepper.com