

Care + Maintenance for Writing Surfaces with Dye Sublimated Images (Murerase)

NORMAL CARE

Murerase white boards may be washed as often as required.

Use clean water or any cleaner specifically sold to be used on dry erase surfaces (e.g., Expo®).

NOTE: Board cleaner may damage lacquer finish on wood framed boards.

DO NOT use abrasive cleaners on the marker board surface as they will scratch the surface, reducing or eliminating the dry erase properties of the surface.

DO NOT use cleaners that contain disinfectants. Some disinfectants will remove the dry erase finish.

For environments that require disinfectants, we suggest the use of isopropyl.

Permanent markers (e.g., Sharpie® pens) will stain the surface of Murerase boards. Remove permanent ink with a dry erase cleaner or a solvent such as mineral spirits. Small amounts of permanent marker may be removed by overwriting the permanent ink with dry erase markers and erasing quickly.

Low-odor markers tend to erase with more difficulty and may require more frequent cleaning.

Dry erase marks that have been left on the board for more than 12 hours may need to be wet cleaned using the methods described above.

Erasers saturated with dry erase ink will cease to be effective. Replace them once this occurs.

EXCEPTIONAL CARE

Permanent markers, marker residue, lipstick, fingernail polish, and like substances can be removed from the Murerase marker boards with isopropyl alcohol or mineral spirits without causing damage to the writing surface. Simply clean, rinse well with water and allow to dry completely.

DO NOT use sharp instruments to remove adhesives or other foreign materials.

Use the solvent recommended by the manufacturer of the foreign materials and clean the surface completely immediately after use with water to rinse the surface.