



iBooth Installation Guide

1. Mount the wall bracket with appropriate fasteners for the wall condition. Make sure the wall bracket is plumb and level. For standing height work surface (42"), mount top of the wall bracket at 58" from floor. For other work surface heights, adjust as necessary.

2. The cleat is pre-installed on the iBooth side or front as specified. Confirm that it is securely fastened. Lift the iBooth onto the wall bracket, inserting the tabs into the top of the bracket openings.



3. With the iBooth in place, secure the lower bracket to the wall bracket using (2) M6 screws included. Insert the screws into the upper (2) holes on the table bracket located under the work surface. Make sure to align the screws with the threaded inserts in the wall bracket, tighten in place.



PLEASE NOTE: THESE INSTRUCTIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.